

CHOPSTICKS



A13-017	4560128871518
5膳箸セット テック	20/10 = 200
CHOPSTICKS 5PAIR "CHECK"	



A13-017-1	4560128871525
5膳箸セット ウサギ	20/10 = 200
CHOPSTICKS 5PAIR "USAGI"	



A13-017-2	4560128871532
5膳箸セット 格子	20/10 = 200
CHOPSTICKS 5PAIRS "KOUSHI"	



A13-017-3	4560128871549
5膳箸セット ウインドウ	20/10 = 200
CHOPSTICKS 5PAIRS "WINDOW"	



A13-017-4	4560128872041
台紙付 スス竹5膳箸 玉虫カラー5色	10/20 = 200
CHOPSTICKS 5PAIRS	



A13-017-5	4560128872058
台紙付 白竹5膳箸 パステルカラー5色	10/20 = 200
CHOPSTICKS 5PAIRS	



A13-017-6	4560128872065
台紙付 白竹5膳箸 ダークカラー5色	10/20 = 200
CHOPSTICKS 5PAIRS	



A13-017-7	4560128872072
台紙付 スス竹 5膳箸 5色	10/20 = 200
CHOPSTICKS 5PAIRS	



A13-017-8	4560128872089
台紙付 スス竹 5膳箸 5色	10/20 = 200
CHOPSTICKS 5PAIRS	



A13-017-9	4560128872096
台紙付 スス竹 5膳箸 花柄 5色	10/20 = 200
CHOPSTICKS 5PAIRS	